Body Worn Camera DOCK STATION
Model CCBWDS20 User Manual

1. Client-side operation software "Station"

Run "Station" as administrator to operate the Client-side software.

1.1 Device Registration

Run "Station" application (see below Figure 1).
Note: If there is no such interface appearing, please check whether there is "posset.dat" file in file "Station" in C-disk. If do, please delete it!

- Insert 1pc BWC into the first interface at the top left of the data acquisition station (see the left picture shown in Figure 2), when it shown "position is ok", It means that this interface's number is 0.
While insert BWC into this NO 0 interface to download data, end user could evaluate whether the transmitting of the BWC data in NO 0 interface is finished or not.

- Pull out the BWC and insert it into the second interface of the data acquisition station which is with red border (refer to the right side picture of Figure 2), Red border means that the interface has not been positioned. With the same method as the first one to position the following 7pcs interfaces until all interfaces have been positioned. Then click the bottom button "Apply", it will show result in Figure 2.


Figure 1

Figure 2

1.2 Device Registration

When camera position finished, the user first inserts the camera to docking station at the first time, the system will prompt to register.

If there is no personnel in the system, please click the management button to log in to the background.

management system and add the organization and personnel (refer to 2.2.1) in the trace of system management-user

management. While the addition is completed, enter the user number in the registration interface of the acquisition

interface and click the query to register.


1.2 Data Import

While camera has been registered and connected to docking station, data in camera will be exported to docking station

automatically and deleted directly. Meanwhile camera will charge automatically. Refer to following figure.

1.3 Set

Operating ·Station· and click ·Set·, input password 123456 while working as admin, user can change some information as following.

1.4 Manage setting

Choose "Manage" in client-side software to enter into data management platform. Default administrator account is "admin" and password is "ttt@admin". Account "admin" is used to maintain the basic information and configuration.

2 Data Management Platform Software

2.1 Administrator login

Login platform with account of ·admin· to manage the devices.

2.2 System management

2.2.1 User Management

Choose ·user· in ·system·, choose the highest level and press ·create· to create a new unit and create new department in

the same way. Input the department and unit in the popup windows. Create the user in the right side ·user management·. Input the details as office number (user ID), device ID, user name, group (shown in the left) etc.

1:Choose "headquarter" and click "Create"

2: Fill the group information

2.2.2 Role Management

Click ·Role· and press ·create· to create a new role and authorize the right of each role while click the rights shown in

the frame.

2.2.3 Operation log

Click -operation log- to check the operations.

System menu	Operation	Description	Operastion user	Full name	IP	Operation time
User	Create	Officer ID606	admin	系统超级管理员	192.168.0.59	2019-09-22 17:39:28
Role	Edit	Name:administrator	admin	系统超级管理员	192.168.0.59	2019-09-22 17:37:12
Role	Edit	Name:officer	admin	系统超级管理员	192.168.0.59	2019-09-22 17:36:59
System Setting	Save	Modify	admin	系统超级管理员	192.168.0.59	2019-09-22 17:30:43
System	Login	admin	admin	系统超级管理员	192.168.0.59	2019-09-22 17:18:32
System operation	Import	Import file: 502@20190922153750@201...	502	GARY	127.0.0.1	2019-09-22 15:52:25
System operation	Import	Import file: 502@20190922153750@201...	502	GARY	127.0.0.1	2019-09-22 15:52:25
System operation	Import	Import file: 502@20190922153750@201...	502	GARY	127.0.0.1	2019-09-22 15:52:24
System operation	Import	Import file: 502@20190922153750@201...	502	GARY	127.0.0.1	2019-09-22 15:52:14
System operation	Import	Import file: 502@20190922153750@201...	502	GARY	127.0.0.1	2019-09-22 15:51:49
System operation	Import	Import file: 502@20190922153750@201...	502	GARY	127.0.0.1	2019-09-22 15:51:03
System operation	Import	Import file: 502@20190922153750@201...	502	GARY	127.0.0.1	2019-09-22 15:50:15
System operation	Import	Import file: 502@20190922153750@201...	502	GARY	127.0.0.1	2019-09-22 15:49:29
System operation	Import	Import file: 502@20190922153750@201...	502	GARY	127.0.0.1	2019-09-22 15:48:31
System operation	Import	Import file: 502@20190922153750@201...	502	GARY	127.0.0.1	2019-09-22 15:47:15

2.2.4 System setting

Press -configuration- and set the system.

System settings

🔄 Refresh | 💾 Save

System name

System name: Data Management Platform Software

Data Management Terminal: Data Management Terminal

Data cleaning

Clear Cycle(Day): 0

Immediately clear: Immediately clear

Disk space: D:1.1%

System backup

Auto backup cycle: One week

Last backup time:

System restore: Restore

Manual backup: Manual backup

Manual restore: Select a backup file

Delete log

Operation log: ◯ One   ◯ Three   ◯ Half year   ◯ One year   ⦿ Not delete

2.3 Data Management (Media Data)

2.3.1 Data Management (Media Data)

Press ·Media Data· and choose the user to check the upload data such as audio, video and photo etc. User could search

the defined user and clarify and mark the data.

	Office number	Full name	Group name	Type	File name	Device ID	File byname	Import time	Recording time	AUTO tag	Task type	Video d...
☐	502	GARY	Unitek	Audio	20150101-000443-0...	801169	502@201909221537...	2019-09-22 15:37:50	2019-09-22 15:52:25	Normal	on and off sign	-
☐	502	GARY	Unitek	Photo	20150101-024155-0...	801169	502@201909221537...	2019-09-22 15:37:50	2019-09-22 15:52:24	Normal	on and off sign	-
☐	502	GARY	Unitek	Video	20150101-023950-0...	801169	502@201909221537...	2019-09-22 15:37:50	2019-09-22 15:52:14	Normal	on and off sign	2Minute
☐	502	GARY	Unitek	Video	20150101-022448-0...	801169	502@201909221537...	2019-09-22 15:37:50	2019-09-22 15:51:49	Normal	on and off sign	4Minute
☐	502	GARY	Unitek	Video	20150101-021447-0...	801169	502@201909221537...	2019-09-22 15:37:50	2019-09-22 15:51:03	Normal	on and off sign	10Minut
☐	502	GARY	Unitek	Video	20150101-020447-0...	801169	502@201909221537...	2019-09-22 15:37:50	2019-09-22 15:50:15	Normal	on and off sign	10Minut
☐	502	GARY	Unitek	Video	20150101-015448-0...	801169	502@201909221537...	2019-09-22 15:37:50	2019-09-22 15:49:29	Normal	on and off sign	10Minut
☐	502	GARY	Unitek	Video	20150101-014448-0...	801169	502@201909221537...	2019-09-22 15:37:50	2019-09-22 15:48:31	Normal	on and off sign	10Minut
☐	502	GARY	Unitek	Video	20150101-013448-0...	801169	502@201909221537...	2019-09-22 15:37:50	2019-09-22 15:47:16	Normal	on and off sign	10Minut
☐	502	GARY	Unitek	Video	20150101-012448-0...	801169	502@201909221537...	2019-09-22 15:37:50	2019-09-22 15:46:00	Normal	on and off sign	10Minut

2.3.2 Dask Type management

Prepare to type or mark the data type according to the work situation such as traffic, demonstration.

Task type

	Name	Description	Created time
☐	on and off sign	on and off sign	2014-07-06 14:31:35
☐	traffic	traffic record	2014-07-06 14:31:10

2.4 Evaluation

2.4.1 Officer Evaluation

Evaluate the related user in the group, such as file quantity, video length etc, and could be export with excel sheet.

Officer Evaluation

Group name	Office number	Full name	Video duration	Status	Quantity	Video	Photo	Audio
Unitek	808	LOI	5Hour23Minute24Seco...	-	47	37	7	3
Unitek	502	GARY	2Hour31Minute57Seco...	-	33	31	1	1
Unitek	503B	MK	2Hour27Minute30Seco...	-	25	21	2	2
Unitek	503	ALAN	29Minute42Second	-	20	14	3	3

2.4.2 Group evaluation

Evaluate the whole unit or department. Evaluation content could be exported in excel sheet.

Group						
Recorded from: [ ] to: [ ] 🔍 Search | ⟲ Reset | ⟳ Refresh | ↗ Export						
Group name	Officer	Video duration	Quantity	Video	Photo	Audio
◢ 🔗 Headquarter	7	10Hour52Minute33Second	125	103	13	9
🔗 Unitek	4	10Hour52Minute33Second	125	103	13	9
🔗 Traffic	1	-	0	-	-	-

2.4.3 Task type

Evaluate the work type and which one is with largest quantity.

Taks type											
Office number: [ ] Full name: [ ] Group: [Please select a gr ▼] Recorded from: [ ] to: [ ] 🔍 Search | ⟲ Reset											↗ Export
Group name	Office number	Full name	交通疏导	违法查纠	服务群众	突发事件	接警出警	现场勘察	调查取证	traffic	on and off sign
Unitek	503	ALAN	0	0	0	0	0	0	0	0	0
Unitek	503B	MK	0	0	0	0	0	0	0	0	0
Unitek	502	GARY	0	0	0	0	0	0	0	0	10
Unitek	808	LOI	0	0	0	0	0	0	0	0	0

2.5 Device management

Choose "device management" to management each registered camera.

Sim Lim Square 02-81 Whatsapp +65 98534404